



5. Setting of Equipment Running Hour on the web platform

Log in to the website of OLISS, Click in turn to enter "Maintenance→Maintenance Management → Eqpt Running Hour" interface according to the following steps 1-5 to set equipment running hours:



1. Click "Eqpt Running Hour"

2. Select the specific equipment information and click "Add" on the right side



3. Fill in the current record time, update total running hours

4. Click to adjust the running time of individual maintenance items separately

5. Click "Confirm"