How to set whether a vessel generates maintenance tasks or not (document)

Users log in to the OLISS Web side, click to enter the "Vessel Management → Vessel Info." interface, click to switch to "Construction Information", click "Edit", click the arrow to select whether to generate maintenance tasks, and click "Confirm" after selection.

Note: For ships that have already generated maintenance tasks in the current month, no maintenance tasks will be generated in the following month.



