

6. How to set oil inspection plans

After the user logs in to the website of OLISS, click "Maintenance → Oil Inspection" in order. On the oil inspection interface, you can follow steps 1-5 as follows:





Note:

According to the inspection plan, the corresponding periodic inspection task will be displayed in Oil Detection interface, as shown below:

