
How to execute stock-in/stock-out operations quickly in "Vessel Stock" interface

Users can log in to the website of OLSaaS, and operate in "Stock Management → Vessel Stock → Spare Parts" interface according to the following steps 1-5:



4.Fill in the stock-in information(Items with * are required)according to the actual situation, and then click "Confirm"





| Spares Name: 大号O型圈 Equipment Info.: 柴油机/M20/Mak/3/2-W | | | opare rai es couer rico | | Location Number: 99 | 9 |
|--|---------------|---------|------------------------------------|--------------|-----------------------|---|
| No. | Stock-in Date | Price | Stock Info.Description | Qty In Stock | Stock-out Qty Remarks | 5 |
| 1 | 2022-04-10 | CNY0.00 | P.I.C.:大管轮 Storage Location:备件库 | 2(个) | | |
| 2 | 2022-11-28 | CNY0.00 | P.I.C.:大管轮 Storage Location:备件库 | 8(个) | | |

5. Fill in the stock-out quantity and remarks(if any)according to the actual situation, and then click "Confirm" to add stock-out items successfully.



Note:

This document shows spare parts as an example. After the operation of Stock-in/Stock-out, the related documents will be generated in "Stock-in/Stock-out Management", "Correction" for stock-in and "Consume" for stock-out.