

How to set equipment running hours

Users can log in to the website of OLSaaS and operate in Dashboard interface according to the following steps 1-5:

1. Log in to the website of OLSaaS, enter the Dashboard interface by default, and click "Add Oil Detection" under "Shortcut"

2. Click to enter the interface for adding the running hours of this equipment

No.	Eqpt Name	Eqpt No.	Eqpt Type	Total Running Hours	Daily Running Hours	Maintenance Plan Q...	Last Add Hours	Last Add Time	Operation
1	1#柴油发电机原动机	GD-0100-000-001	6135J2CAF	9289	10	11	300	2023-01-22 10:37	Add
2	2#柴油发电机原动机	GD-0200-000-001	6135J2CAF	1221	12	11	111	2022-11-01 09:55	Add
3	停泊发电机原动机	GD-0300-000-001	2135ACAF	1601	24	11	1600	2021-11-18 16:27	Add
4	右主机	M02	6230ZC	4000	12	14	1	2022-08-29 08:49	Add
5	主机	MD-0100-000-001		4330	24	33	350	2022-09-13 14:25	Add
6	右主机	MD-0100-000-002		6000	24	34	0	2021-04-14 18:14	Add

3. Fill in the current record time, update total running hours

4. Trial calculation results of the next maintenance date

5. Click "Confirm"

Note:

The more frequent reading of equipment running hour, the more accurate the next maintenance date calculated by the system.